

**DANCOVER<sup>®</sup>** 

Manual  
for  
E-Scooter

## The instructions of display LH-100


(Special for scooters)

The vision of 2018-V1.1




### 一、Product specification


The shell of the product is ABS. The transparent window is crystal with high hardness acrylic, hardness value is equivalent to toughened glass.



Elevation



Side elevation



### The support of LH-100


## 二、 Working Voltage and the Mode of Connection

1. Working Voltage: DC24V/36V/48V ( display choose by itself)

And we also can set the voltage.

2. Mode of connection

Standard connection



The connector with controller



The connector with display



The connector with Butted line

The line number	The color of the line	Function
1	Red(VCC )	The power of the display
2	Blue ( K )	The power of the controller
3	Black ( GND )	Earth line of display
4	Green ( RX )	The data acceptance line of display
5	Yellow ( TX )	The data transmission line of display

Some display use waterproof plug-in components,so it cann' t see the color of the line.

### 三、Function

#### 1. Show content:


The content of speed、 power、 hitch、 Total mileage、 Single mileage

#### 2. The function of controll and setting:


Controller the switch power、 Wheel diameter setting、 Idle automatic sleep time setting、 Backlight setting、 Startup mode setting、 Drive mode setting、 Voltage level setting、 Controller Current Limit Setting、 USB charging function

#### 3. Communicating Protocol:URAT

All content on display(power on within 1 second)



##### 3.1 Voltage level




##### 3.2 Multifunctional display area



Total mileage **ODO**、Single mileage **TRIP**、Digital voltage display **VOL**、Fault code **ERR**

Fault code (decimal system)	fault condition	remarks
0	Normal status	
1	keep	
2	brake	
3	PAS sense hitch ( Riding sign )	Not implemented here
4	6KM/H cruise	
5	Real-time cruise	
6	Battery undervoltage	
7	Motor fault	
8	Turnstile fault	
9	Controller fault	
10	Communication receiving fault	
11	Communication transmission failure	
12	BMS communication failure	
13	Headlamp failure	

### 3.3 Speed display area



Unit : MPH, KM/H

The speed signal is taken from the Hall signal inside the motor.Sent to controller by controller(Time of single Hall period,unit:1MS).The display calculate the true speed based on

wheel diameter and signal data calculate the true speed(The motor Holzer also needs to set the number of magnetic steel)

3.4 Vehicle power gear adjustment ,




0-9 digital display;

3.5 vehicle status display area



Zero start and non-zero start prompt



The headlight turns on the prompt;



Constant speed cruise hint;



Communication fault prompt;



USB charging hint

#### 4. Setting

P01 : Backlight brightness:The 1 level is the darkest , Level 3 brightest ; Default: 3

P02 : Mileage: unit,0 : KM ; 1 : MILE ; Default: KM

P03: Voltage level: 24V , 36V , 48V , 52V , 60V, Default:52V

P04: Dormancy time:0 means no dormancy;Other numbers are dormant time.The range is  
1-60 minute.Default:5

P05: Reserve

P06: Wheel diameter: The unit is inch. The accuracy is 0.1; Default:10.0

P07: Speed measuring magnetic steel number.The range is 0-255. Default:28

P08: Rate-limiting: The range is 0-100km/h.Default: 100

P09: Zero start、 no zero start setting ; 0 means zero start.1means no Zero start.Default: 0

P10:Reserve

P11: EABS switch choose.The range is 1-5.0 means closing.1 means weakest.2 means strongest.

P12: Soft and hard start strength.The range is 1-5. The softest is 1.The hardest is5.Default: 3

P13: Reserve

P14: Reserve

P15: Controller under-voltage

P16: ODO Zero setting: keep pressing + for 5 seconds,ODO will zero clearing.


P17: When it shows 0,it can not use cruise.When it shows 1,it can use cruise.Default:0

P18: Reserve


P19: Reserve


P20: Communication protocol is defaults 4.It can not change.



### 三、 Introduction of buttons and interfaces




1. When it is shutdown, long-time pressing  to turn on the power. When it is power

on ,It can change interface between the ODO、 TRIP、 VOL, by pressing  for short time.

2. When it is power on, long-time pressing  to turn off, short-time pressing can change gear.

3. Long-time pressing  and  can get into the menu to change the interface.

4. Get into the setting interface, short-time pressing  can change parameter.

Short-time pressing or long-time pressing can add or reduce the numerical value. After

changing, short-time pressing  to change the next numerical value. After

changing, long-time pressing  and  to get out of the interface, or waiting 8 seconds, it can save the numerical value and drop out by itself.

五、Crankshaft regulating motor speed by Up and down, Motor speed increase; relax hand it return to zero.



# DANCOVER<sup>®</sup>



## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

### National contact

Denmark: 70 26 76 20  
[denmark@dancover.com](mailto:denmark@dancover.com)

UK: 020 8099 7570  
[uk@dancover.com](mailto:uk@dancover.com)

Germany: 041 0266 7040  
[germany@dancover.com](mailto:germany@dancover.com)

France: 0975 181 800  
[france@dancover.com](mailto:france@dancover.com)

Sweden: 040 233 262  
[sverige@dancover.com](mailto:sverige@dancover.com)

Finland: 0 931 581 720  
[suomi@dancover.com](mailto:suomi@dancover.com)

Poland: 22 300 8602  
[polska@dancover.com](mailto:polska@dancover.com)

Luxembourg: +49 041 0266 7040  
[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

Portugal: 308 800 899  
[portugal@dancover.com](mailto:portugal@dancover.com)

Spain: 911 436 828  
[espana@dancover.com](mailto:espana@dancover.com)

Italy: 02 479 21 198  
[italia@dancover.com](mailto:italia@dancover.com)

Switzerland: 0840 000125  
[schweiz@dancover.com](mailto:schweiz@dancover.com)

Austria: 0662 626935  
[austria@dancover.com](mailto:austria@dancover.com)

Norway: 231 00 690  
[norge@dancover.com](mailto:norge@dancover.com)

Nederland: 0 858 880 524  
[nederland@dancover.com](mailto:nederland@dancover.com)

Ireland: 0 151 33 003  
[ireland@dancover.com](mailto:ireland@dancover.com)

Belgium: 0 28 08 08 09  
[belgique@dancover.com](mailto:belgique@dancover.com)